

SECOLO DOCUMENT AND DATA CARRIER DESTRUCTION



Reliable data protection and automatic documentation



Professional security and process management for collecting containers.
Comply with the guidelines of the EU-GDPR and benefit from numerous advantages at the same time.

Thanks, innovative technology, the SECOLO container locking and management system stands for the highest security standards in document and data carrier destruction, but at the same time enables the optimization of customer service and more efficient handling and administration processes. Offer your customers the opportunity of optimal data protection for information on documents and electronic data carriers which will be destroyed.

At the same time, you simplify the key management, get full documentation and you always know where your containers are. Installations at numerous satisfied customers in Europe and Asia are the best reference for how easy the SECOLO system is to use and how reliable it is in operation.

SECOLO DOCUMENT AND DATA CARRIER DESTRUCTION



Reliable data protection and automatic documentation

Leading edge by innovative technology

Thanks, the combination of management software, handheld app and RFID lock with RFID tracking function, the SECOLO system is a comprehensive, well-rounded solution that meets current and future security requirements. Individually programmable container locking authorizations allows more efficient use of the containers as with mechanical locks. This is because empty collection containers can be issued to any customers without ending-up that every customer key is locking every container of other customer as well, as it is with most mechanical locking system. Finally exclusive locking authorizations for every customer!

FMTEC's smart Marker-technology ensure that containers in the truck or at the tilting of the central shredder can be wireless un-

locked automatically to ensure that no person can read or take any document.

The integrated RFID-tracking function provides a better overview where the collection containers are and combined with the logging of unlocking and alarms it facilitates the obligation to provide evidence in favour of compliance with the EU-GDPR.

Further advantages: Existing collection containers can be retrofitted with the electronic lock. It is also possible to fully manage containers without an electronic lock in the SECOLO system by using barcodes as container-ID.

Advantages with SECOLO-System

- > Exclusive locking authorisations for each customer using RFID-chip keys, instead of the same locking authorisations for all containers due to the limitations of mechanical locks.
- > Fulfilment of the EU-DSGVO regarding data protection through technical measures.
- > Fulfilment of the obligation to provide evidence according to EU-DSGVO by comprehensive documentation of all accesses and events.
- > Person-less, automatic container unlocking via RFID technology to fulfil security class 3 and higher.
- > Risk minimization by acoustic alerting the customer when the lid has been open for too long.
- > Efficient overview thanks to container handover via SECOLO-App on mobile device.
- > Space and cost savings by reducing the number of empty exchange containers on stock.
- > Modern and user-friendly management software (SQL-DB) and App for mobile devices. Useable for collection containers with and without electronic lock.

SECOLO software modules

The modular design of the SECOLO-Software allows the system to be specifically adapted to individual requirements. Thanks to its infinite scalability, the SECOLO container management system is also suitable for any safety level and any size of customer.

SECOLO Management Center

Configuration of the system, management of access rights, evaluation of events, and optimized process logic. The flexible interface concept makes data-exchange with third-party applications easy.

SECOLO Global Management

The SGM software enables monitoring, tracking and control of the SECOLO security containers, as well as alerting in case of exceptional situations.

SECOLO App

Thanks, the smart app - SECOLO Mobile Management" for mobile devices the handover and all other process steps are quick and easy. According to the requirements for process mapping FMTEC develops apps for handhelds and mobile phones.



SL1000

- > RFID data carrier
- > 4-eyes principle
- > RFID-Tracking



SL1001

- > PIN-Code
- > RFID data carrier
- > RFID data carrier + PIN
- > 4-eyes principle
- > RFID-Tracking

