

SECOLO SAFE-S

SECOLO Smart Locks in robust aluminum containers protect what is important to you.



STAY INFORMED
with our Newsletter.

SECOLO SAFE-S

The easy solution for secure transportation and storage of confidential documents, valuable equipments and materials.

Discover with our "all-inclusive package"- SECOLO SAFE-S, how easy and intuitive it is to achieve perfect protection for your documents and valuable goods.

The lightweight, yet sturdy and resistant aluminium container of highest quality offers excellent, flexible and durable access protection for your transport good with the unique SECOLO RFID lock. The steel cable to anchor prevents the quick theft of the SECOLO SAFE in a simple but effective way - in a vehicle, on a construction site or anywhere else.

The professional design ensures high physical resistance despite the light metal, while the electronic lock guarantees fast and secure access for authorised personnel. Authorisations are activated simply, quickly and securely using the PIN keypad.

The SECOLO SAFE-S is a product for everyone and should not be missing in any company. Make no compromises in the areas of security, functionality and convenience. FMtec has the right solution for you.

Applications

- > Transportation of valuable goods by car
- > Transportation of data carriers
- > Transportation of medicines or laboratory samples
- > Transportation of valuable machines or measuring equipment in a minibus
- > Storage of documents or plans on the construction site
- > Storage of expensive measuring equipment
- > Storage of valuable materials
- > Do you have an idea? Let's talk about it.

Available sizes

Article description	Order number	Dimensions (WxDxH) in mm		Volume (l)	Load capacity (kg)	Weight (kg)
		Inside approx.	Outside approx.			
SECOLO SAFE-S GMS1599/42 - SL500 included in the scope of delivery: 1 pc. Anchor Cord AC100x8, 3 pcs. RFID key fobs, 3 pcs. battery compartment key	10001528	553 x 353* x 220	588 x 388 x 250	42	50	5,4
SECOLO SAFE-S GMS1599/73 - SL500 included in the scope of delivery: 1 pc. Anchor Cord AC100x8, 3 pcs. RFID key fobs, 3 pcs. battery compartment key	10001529	553 x 353* x 380	588 x 388 x 410	73	50	6,4
SECOLO SAFE-S GMS1599/239 - SL500 included in the scope of delivery: 1 pc. Anchor Cord AC100x8, 3 pcs. RFID key fobs, 3 pcs. battery compartment key	10001530	753 x 553* x 580	788 x 588 x 610	239	75	9,9
SECOLO Anchor Cord AC100 x 8	10150015	Material: stainless steel coated with transparent plastic / Length: 1.1 m Diameter steel cable: 8 mm / Overall diameter: 10 mm / Loop: 70 mm				
RFID Key Fob KF1356T-TBNC (PU: 5 pcs.)	10001602	Drop shape, blue/white, with unique number				
RFID Key Card KC1356 (PU: 5 pcs.)	10001603	RFID card in standard format, blank, white with laser-engraved number				

*...In the area of the lock, the depth is reduced by 50 mm

Other container sizes on request.

Security functions

Identification for opening or closing

- > PIN 1 (1 to 12 digits)
- > PIN 1 + PIN 2 (4 to 8 digits)
- > RFID data carriers (cards, key fobs, wristbands)
- > RFID data carrier + PIN 2 = higher security

Types of alarm

- > Lid open too long: If the lid is not closed within a definable time, the lid open alarm starts.
- > Battery warning: Battery replacement required within a few weeks.

Alarm signals

- > Acoustic: via built-in signalling device
- > Optical: via red LED on the control panel

Technical information

- > Up to 50 authorized persons using card, PIN or card + PIN
- > Almost any RFID data carrier (ISO14443 / ISO15693)
- > Battery lifetime up to 10 years (with 3 locking operations per working day)
- > Self-locking or by data carrier / PIN
- > Holder for steel cable available on both sides

Containers

Our innovative professional aluminium containers are lightweight, robust and have a long service life. They are easier to stack and unstack than containers with stacking corners. Thanks to the all-round stacking rim, they can be pushed on top of each other effortlessly - similar to drawers.

- > Professional container with textured, scratch-resistant surface
- > All-round, stable edge profiles on the container rim, base and lid ensure a durable container shape
- > High burglar resistance thanks to large overlap between lid and container
- > Walls (from volume 73 l) reinforced by all-round, trapezoidal beading
- > Lid with hinge, all-round rubber seal and 2 straps
- > Sturdy spring folding handle on both sides
- > 2 lever clamp fasteners (delivery without these fasteners possible)
- > Corner radius 30 mm
- > Stackable and adapted to pallet dimensions
- > incl. electronic SECOLO Smart Lock SL500
- > incl. brackets (left and right) for a safety steel cable
- > incl. 1 steel cable for securing in the vehicle or on the construction site
- > additional steel cable and partition walls for optimum partitioning of the interior are available as special accessories



Operating manuals / brochures
www.fmtec.eu/en/downloads/



FMTEC - Future Management Technologies
 +43 5552 67735-0 | info@fmtec.eu | www.fmtec.eu

FMTEC
 Software Electronics